



KARL'S

EVENT RENTAL

7000 South 10th Street
Oak Creek, WI 53154
(414) 831-7000
www.karls.com

Description

The bullhorn that Karl's Event Rental offers is musical as well. The bullhorn can play different sounds as well as songs. The bullhorn can also be used as a microphone, to address large crowds in an outdoor area. The level of the bullhorn is very loud, so avoid holding it near your ears or any one else's ears.

Controls

The bullhorn has many features and controls. The bullhorn includes a speaker horn, microphone, keyboard, battery compartment, ON/OFF power switch, trigger switch, record button, play button, and detachable shoulder strap.

Operational Features

1. To play a song: Choose a song from the list. Squeeze the trigger and then enter the two-digit number on the keypad. Release the trigger and press PLAY.
2. To record a new song: The keys on the keypad are used as notes to form a song. Squeeze the trigger and enter a number between 01 and 05. Press RECORD. Press the different keys to create your song, when you are finished, press CM to complete your entry. To play back your song, simply enter the number that you assigned to it.

